

# SLIGER



## GENERAL DEVICES

RACK SLIDES REV B

# TABLE OF CONTENTS

---

VERSION 3.0

## **1. PRODUCT INFORMATION**

---

- 1.1 Exploded View
- 1.2 Rail Dimensions - 14"
- 1.3 Rail Dimensions - 20"
- 1.4 Rail Dimensions - 26"
- 1.5 Hardware Kit
- 1.6 Parts of a GD Rail

## **2. RAIL ASSEMBLY AND INSTALL**

---

- 2.1 Rail Installation
- 2.2 Rear Support Installation
- 2.3 Inner Member Removal
- 2.4 Inner Member Installation
- 2.5 Chassis Assembly

## **3. APPENDIX**

---

- 3.1 Warranty Policy
- 3.2 Support and Service
- 3.3 Regulatory Compliance
- 3.4 Revision History

# 1.1 EXPLODED VIEW





Figure 1.1

NO.	PART NAME	NO.	PART NAME
1	Slide Outer Member <b>(Red)</b>	6	M5 x 9mm Screw <b>(C)</b>
2	Slide Center Member <b>(Blue)</b>	7	M4 x 7mm Pancake Screw <b>(A)</b>
3	Slide Inner Member <b>(Green)</b>	8	M4 Keps Nut <b>(B)</b>
4	Front Support Bracket <b>(D)</b>		
5	Rear Support Bracket <b>(E)</b>		

# 1.2 RAIL DIMENSIONS - 14"

GD Rails




Minimum Length: 14.25in / 361.95mm

Maximum Length: 31in / 787.4mm

# 1.3 RAIL DIMENSIONS - 20"

GD Rails




Minimum Length: 20.25in / 514.35mm

Maximum Length: 37in / 939.8mm

# 1.4 RAIL DIMENSIONS - 26"

GD Rails



Minimum Length: 26.25in / 666.75mm

Maximum Length: 43in / 1092.2mm

# 1.5 HARDWARE KIT AND PARTS

 We recommend tightening all fasteners by hand to minimize damage to the chassis and fastener. 

## **A. PAN HEAD SCREW M4-0.7 x 7mm** 16x

Rear Supports to Outer Slide **and**  
Inner slide to chassis



## **B. KEPS NUT M4-0.7** 6x

Use with Pan Head Screw **A**.

Secures rear support bracket to rail.



## **C. SCREW M5 x 9mm** 10x

Secures front and rear extensions to rack



## **D. FRONT SUPPORT BRACKETS** 2x

Use with Screw **C**.

Secures rail slides to rack posts



## **E. REAR SUPPORTS** 3x Pair

Use with Screw **C**.

Secures rail slides to rear rack posts





## **F. RACK RAIL SLIDES** 1x Pair

Use with front supports **D** and rear  
extension **E**.



\*The M4 screws and keps nut have 0.7mm thread pitch

# 1.6 PARTS OF A GENERAL DEVICES RAIL




NO.	PART NAME
1	Inner Slide - Attaches to Chassis
2	Center Slide (Should not be removed during installation)
3	Outer Slide - Attaches to rack posts and Extensions <b>(E)</b>
4a	Retention Tab - interfaces with <b>4b</b>
4b	Retention Stop - Interfaces with <b>4a</b>
5	Locking Tabs

# 2.1 RAIL INSTALLATION

## Step 1

Align the front support bracket **(D)** with the holes in the rack and LOOSELY thread two M5x7mm screws **(C)** through rack post holes and into the front bracket **(D)**. Repeat for the other side.

Figure 2.1-1



## Step 2

Once both front brackets are loosely screwed to the rack, slot the entire rail assembly between the front support bracket **(D)** and the back of the rail and tighten the M5 Screws **(C)**, then repeat on the other side.




Figure 2.1-2





Figure 2.1-3

# 2.2 REAR SUPPORT INSTALLATION

### Step 1


Find the appropriate length of rear support (**E**) for your rack depth. Ensure that the support length you choose does not interfere with the locking tab on the back of the rail.



*\*Steps 2 and 3 can be done in any order.*


### Step 2

Secure the rear support (**E**) to the rack using two M5x7mm Screws (**C**) through the rack post holes and into the rear support (**E**).




### Step 3

Secure the rear support (**E**) to the rail using two M4x7mm Pan Head screws (**A**) through rear support (**E**) and rail (**F**). Secure using two M4 Keps nuts (**B**). The screws can be fed from either side.




## 2.3 INNER MEMBER REMOVAL




### Step 1

Extend the rail by sliding the inner member out first and pulling until you hear the two clicks (per side) of the two locking tabs locking into their holes.



### Step 2

While depressing the release button circled below, slide the inner member completely out of the slide assembly as pictured at top (Figure 2.3-2a). The inner member must be removed from both rails before the chassis can be attached to the rails.



## 2.4 INNER MEMBER INSTALLATION

GD Rails

### Step 1

Line up the inner member of the rail with the holes on the center line of the chassis.

Make sure the tab on the rear of the rail is at the rear of the chassis.




Figure 2.4-1

### Step 2

Install M4x7mm Pan Head screws (**A**) through the rail into the chassis. The number of M4 screws required will vary between models; typically 3-5 per side




Figure 2.4-2

# 2.5 CHASSIS INSTALLATION

## Step 0

If you did not fully extend the rails in the earlier steps, slide the inner part of the rail outer members forward until you hear a loud click and the inner part stops moving. The release button should be engaged as pictured.




Figure 2.5-0

## Step 1

Insert the inner slides into the extended outer members. Depress the security latches on the inner member so that they do not catch on the center member. Push the chassis in until you hear the security latches engage.




Figure 2.5-1

## Step 2

Press down the security latches one more time to finish sliding the chassis into your rack. The second set of security latches on the center member will be disengaged by the tab at the rear of the inner member as you slide the chassis all the way in.




Figure 2.5-2

# 3.1 WARRANTY POLICY

---

## SUPPORT AND SERVICE

Sliger Designs LLC ("Sliger") warrants its Products, if properly used and installed, against defects in material and workmanship for the period stated on the product specifications. Under normal use and service, every hardware portion of the products will be free from physical defects in material and workmanship during the warranty period (excludes normal wear and tear), or the product will be repaired or replaced as determined solely by Sliger.

For full warranty and RMA policy visit : [https://www.sliger.com/support/warranty\\_and\\_rma/](https://www.sliger.com/support/warranty_and_rma/)

Website: [www.sliger.com](http://www.sliger.com)

Support Email: [orders@sliger.com](mailto:orders@sliger.com)

Phone Number: 1 775 356 5595

Hours of Operation: 8a - 5:30p MST

## 3.2 SUPPORT AND SERVICE

---

### SUPPORT AND SERVICE

If you have any questions or problems with the Sliger product you purchased, please don't hesitate to contact us via email or phone. Please include a detailed explanation of your problem and your order number.

For comments and suggestions, you can e-mail our design team, [orders@sliger.com](mailto:orders@sliger.com).

Lastly we would like to thank you for your support by purchasing this product.

For more information about Sliger Designs, please visit us online.

Support Email: [orders@sliger.com](mailto:orders@sliger.com)  
Phone Number: 1 (775) 356 5595  
Hours of Operation: 8:00a - 5:30p MST  
Website: [www.sliger.com](http://www.sliger.com)

## 3.3 REGULATORY COMPLIANCE



To the best of our knowledge, all computer chassis manufactured by Sliger Designs, LLC adhere to ROHS, REACH, and Conflict Minerals regulations. All Sliger products are produced in the United States of America and primarily utilize domestically sourced materials.

### **ROHS STATEMENT**

This product is compliant to implemented RoHS (Restriction of Hazardous Substances) type regulations worldwide, including but not limited to China, India, Japan, Korea and European Union.

### **REACH STATEMENT**

REACH (Registration, Evaluation, Authorization and Restriction of Chemicals, EC 1907/2006) is the European Union's (EU) chemical substances regulatory framework. REACH requires Sliger Designs, LLC to provide customers with sufficient information on Substances of Very High Concern (SVHC) contained in products in concentration above 0.1% weight by weight (w/w) to allow safe use of the product.

Certificates of Compliance are available upon request.

## 3.4 MANUAL REVISION HISTORY

---

GD Rails

Version 1.0 2024/05/17

Version 1.1 2025/06/18

Version 2.0 2025/08/01

Version 3.0 2025/09/10